

DMC's Controllers and Workable Operation Systems

S1240204C

March, 2024

| for USB I/F | DUSx000 | DUSx200 | TSC-52 | TSC-54/55 | MTR20x0 |
|-----------------|---|---|---|---|---|
| WindowsXP~11* | DMC Driver OS Driver | DMC Driver OS Driver | DMC Driver OS Driver | DMC Driver | DMC Driver OS Driver |
| Linux & Android | Kernel 3.5 or later: OS Driver Kernel 2.6.35~3.4: DMC Driver | Kernel 3.5 or later: OS Driver Kernel 2.6.35~3.4: DMC Driver | Kernel 3.5 or later: OS Driver Kernel 2.6.35~3.4: DMC Driver | Kernel 3.5 or later: OS Driver Kernel 2.6.35~3.4: DMC Driver | Kernel 3.5 or later: OS Driver Kernel 2.6.35~3.4: DMC Driver |
| QNX | QNX 7.1 or later : OS Driver (Not confirmed) | QNX 7.1 or later : OS Driver (Not confirmed) | QNX 7.1 or later : OS Driver (Not confirmed) | QNX4 Product Suite 2010 : OS Driver (Not confirmed) | QNX 7.1 or later : OS Driver (Not confirmed) |

| for UART or RS-232C I/F | DUSx000 | DUSx200 | TSC-52 | TSC-54/55 | MTR20x0 |
|-------------------------|--------------------------|--------------------------|------------|---|--------------------------|
| | UART | UART | RS232C | RS232C | UART |
| WindowsXP~11* | DMC Driver | DMC Driver | DMC Driver | DMC Driver | DMC Driver |
| Linux | kernel 3.14 : DMC Driver | kernel 3.14 : DMC Driver | - | Kernel 3.2 or later : OS Driver Kernel 2.4.22~3.9.5 : DMC Driver | kernel 3.14 : DMC Driver |
| Android | kernel 3.14 : DMC Driver | kernel 3.14 : DMC Driver | - | - | kernel 3.14 : DMC Driver |

| for I2C I/F | DUSx200 | |
|-----------------|--------------------------------------|---------------------------------|
| | Original Protocol | HID over I2C |
| WindowsXP~11* | - | Windows10 or later : OS Driver |
| Linux & Android | Kernel 3.8.13 & 4.14.94 : DMC Driver | kernel 3.8 or later : OS Driver |

*Multi-touch is not available for WindowsXP.

This document is for reference only.

Please test the controller's operation on your actual environment since its functionality depends on the operating system's configuration.

DMC Driver = The Controller operates with a driver provided by DMC.

OS Driver = The Controller operates with a driver on the OS.

If DMC Driver for Linux or Android is needed, please contact us.

